



ASSEMBLY INSTRUCTIONS:

1. TILT THE RIGHT SIDE PLUG AND PUSH INTO GAP
2. FLATTEN THE PLUG AGAINST THE BOTTOM RAIL AND INSERT FULLY
3. REPEAT WITH LEFT SIDE PLUG ON OPPOSITE SIDE OF WINDOW
4. WHILE NOT NECESSARY FOR INSTALLATION, SILICONING PART INTO PLACE MAY ADD ADDITIONAL WATER PROTECTION

NOTES:

- YOU MAY NEED TO PUSH WITH A SCREWDRIVER TO FULLY INSERT THE PLUG